Cracked sample sets

Trueflaw produces real cracks for NDI purposes. Cracks can be produced to custom samples provided by the client or provided as ready-made samples. Ready-made sample sets provide a cost effective alternative to custom samples and can be used for process verification, vendor evaluation or POD estimation. All cracks are natural thermal fatigue cracks and can be used for any NDT-method.



Single sample to complement TAM-panel

Three true cracks
Ti-6Al-4V
Check your process with real cracks



Small sample set for training or vendor evaluation

5 Samples 15 cracks, Sizes 0.3 ... 3 mm Randomly oriented Develop and evaluate your process with real cracks



POD point-estimate set

10 plates
29 cracks
Randomly oriented
90/95 POD point estimate (29/29)



POD set

30 plates 87 cracks Randomly oriented For full ASTM-E2862 or Mil-HDBK-1823A POD analysis

Contact

http://trueflaw.com/pod trueflaw@trueflaw.com +358 45 6354415

